Bearing retention	90
Radial retention	90
Axial retention	91
Positioning of single bearing assemblies	91
Positioning of two bearing assemblies	92
Axial retention processes	93
Bearing seats	96
Bearing tolerances	96
Shaft and housing seat tolerances	97
Recommended fits	98
Value of tolerances and fits	100
Geometry and surface conditions of shaft and housing seats	106
Radial clearance of radial contact bearings	109
Residual radial clearance : definition, calculation	109
Ratio of interference effect on clearance	109
Residual clearance after fitting: J _{rm}	110
Choice of internal clearance as a function of shaft and housing fits	112
Calculation of residual clearance in operation	112
Axial clearance	
of angular contact bearings	115
Axial preload	115
Axial penetration and prelaod	115
Determining the preload	116
Adjustment	117
Theoretical calculation of the variation in the axial clearance of an assembly	117
Modification of clearance on assembly	117
Theorical calculation of the variation in the axial clearance of an assembly	118

SNR

Bearing retention

Radial retention

The bearing rings must be assembled with the mounting elements (shaft and housing) such that they become an integral part of them. The means of connection must prevent any relative movement of the rings on their seat under the radial and axial loads, while maintaining the precision of the bearing, its operating clearance, its limit loads, speed, temperature, etc.

Under the action of the radial load, one of the two rings of a rotating bearing is "rolled" between the rolling elements and its seat, and tends to turn on it. This relative displacement must be prevented to avoid wearing of the seat (bearing hardness: 62 HRC).

General rule

The ring that rotates with respect to the load direction must be press fitted on its seat.

	Analysis of rotation	(cases frequency)	Retention principle
Load stationary with respect to the outer ring	Stationary housing and load (95 %)	Rotating housing and load (0.05 %)	Inner ring interference-fitted on shaft
	Rotating inner ring	Stationary inner ring	
Load stationary with respect to the inner ring	Stationary shaft and load (3 %)	Rotating shaft and load (1.5%)	Outer ring interference-fitted in the housing
	Outer ring rotating	Outer ring stationary	

The bearing rings are usually retained with an interference fit. Other methods of retention do exist as: adapter sleeves (see page 139), eccentric locking collars or set screw on inner ring, gluing, etc. The seat fits are chosen from Standard ISO 286 according to the bearing operating criteria.

90

Axial retention

The bearings secure the axial positioning of the rotating part of a component with respect to the stationary part.

→ Positioning of single bearing assemblies

Retention of bearing assemblies requires one bearing to float axially to prevent stresses due to thermal expansion



Fixed assembly with two bearings

The fixed assembly may be made up of two associated bearings, depending on the assembly specifications.



Bearing retention (continued)

Positioning of two bearing assemblies

The principle of this assembly is to have one assembly limiting axial displacement of the shaft in one axial direction, while the other assembly limits it in the opposite direction.

This implies that one of the bearing rings must be free to move axially on its seat to permit assembly. The operating axial displacement then depends on the axial adjustment of the relative position of the inner rings with respect to the outer rings.



Radial contact bearings

This type of assembly can be used with the various types of radial contact bearings: ball bearings, cylindrical roller bearings, self-aligning and spherical bearings. A minimum axial displacement must apply, which varies according to the types of assembly.



92

Angular contact bearings

Angular contact bearings get their rigidity through their fitting. They have to be adjusted to secure the relative positioning and the operating clearance.

Two types of assembly are possible:

Face-to-face assembly (O): the points of load application are located outside the bearings.



Back-to-back assembly (X): the points of load application are located between the bearings.



Axial retention processes

Inner ring

Nut and washer



Cylindrical seat. Tight fit against shoulder.



Tapered seat, therefore bearing with tapered bore. Preferential direction of axial thrust (\rightarrow) .

Snap ring



Easy and fast to fit, occupies little space.



A thrust washer must be installed between the inner ring and the snap ring if axial load is high.



93

Bearing retention (continued)

Adjusting ring

Reserved for shaft ends.



Press fit ring

Preferential direction of axial thrust (\rightarrow) . The ring has to be destroyed to remove the bearing.



Sleeve

Preferential direction of axial thrust (➔). Does not need precise machining of the shaft. Above all used for spherical roller bearings.



Outer ring

Сар

Necessary gap between cap and face of casing.



Snap ring



Easy and quick to mount, occupies little space.



A thrust washer must be installed between the outer ring and the snap ring if axial load is high.

Note : the snap ring (with or without a thrust washer) can replace a shoulder.

Snap ring built in the bearing (type NR bearing)



Necessary gap between the cap and the face of the housing.



In the particular case where the housing is in two parts, the ring can be installed between the two parts.



Bearing seats

Bearing tolerances

Under the action of the radial load, one of the two rings of a rotating bearing tends to turn. To avoid wearing the seat, this relative displacement must be prevented by having an appropriate fit. The fit of the other ring will allow axial displacement on the seat (adjustment, thermal expansion).

Standard precision bearing tolerances

Inner ring

Deviation with respect to the nominal bore

Outer ring

Deviation with respect to the nominal diameter

Bore d	All bearings except tapered roller bearings ∆dmp (µm)		Tapered roller bearings ∆dmp (µm)			Outside diameter D		Outside diameter D		All bea exc tape roller b ∆Dmp	arings ept ered earings (µm)	Tape rol bear ∆Dmp	ered ller rings (µm)
2,5 <d≤ 10<="" td=""><td>max. O</td><td>min. -8</td><td>max.</td><td>min.</td><td></td><td>6 <[</td><td>)≤</td><td>18</td><td>max. 0</td><td>min. -8</td><td>max.</td><td>min.</td></d≤>	max. O	min. -8	max.	min.		6 <[)≤	18	max. 0	min. -8	max.	min.	
10 <d≤ 18<="" td=""><td>0</td><td>-8</td><td>0</td><td>-12</td><td></td><td>18 <[</td><td>)≤ ;</td><td>30</td><td>0</td><td>-9</td><td>0</td><td>-12</td></d≤>	0	-8	0	-12		18 <[)≤ ;	30	0	-9	0	-12	
18 ~d< 30	0	-10	0	-12		30 <[)≤ (50	0	-11	0	-14	
$30 < d \le 50$	0	-12	0	-12		50 <l< td=""><td>)≤ (</td><td>30</td><td>0</td><td>-13</td><td>0</td><td>-16</td></l<>)≤ (30	0	-13	0	-16	
50 <d≤ 80<="" td=""><td>0</td><td>-15</td><td>0</td><td>-15</td><td></td><td>80 <[</td><td>)≤ 1: < 1</td><td>20</td><td>0</td><td>-15</td><td>0</td><td>-18</td></d≤>	0	-15	0	-15		80 <[)≤ 1: < 1	20	0	-15	0	-18	
90 de 100	0	20	0	20		150 <[/≤ 18)≤ 18	30 30	0	-10	0	-20	
80 <d≤ 120<br="">120 <d≤ 180<="" td=""><td>0</td><td>-20 -25</td><td>0</td><td>-20 -25</td><td></td><td>180 <[</td><td>)≤ 2</td><td>50</td><td>0</td><td>-30</td><td>0</td><td>-30</td></d≤></d≤>	0	-20 -25	0	-20 -25		180 <[)≤ 2	50	0	-30	0	-30	
180 <d≤ 250<="" td=""><td>0</td><td>-30</td><td>0</td><td>-30</td><td></td><td>250 <[315 <[</td><td>)≤ 3[.])≤ 4(</td><td>15 00</td><td>0 0</td><td>-35 -40</td><td>0 0</td><td>-35 -40</td></d≤>	0	-30	0	-30		250 <[315 <[)≤ 3 [.])≤ 4(15 00	0 0	-35 -40	0 0	-35 -40	
250 <d≤ 315<="" td=""><td>0</td><td>-35</td><td>0</td><td>-35</td><td></td><td>400 <l< td=""><td>)≤ 5(</td><td>JU</td><td>U</td><td>-45</td><td>0</td><td>-45</td></l<></td></d≤>	0	-35	0	-35		400 <l< td=""><td>)≤ 5(</td><td>JU</td><td>U</td><td>-45</td><td>0</td><td>-45</td></l<>)≤ 5(JU	U	-45	0	-45	
315 <d≤ 400<="" td=""><td>0</td><td>-40</td><td>0</td><td>-40</td><td></td><td>500 <[</td><td>)≤ 6;</td><td>30</td><td>0</td><td>-50</td><td>0</td><td>-50</td></d≤>	0	-40	0	-40		500 <[)≤ 6;	30	0	-50	0	-50	

Other precision classes, see page 23.

The shafts are generally machined in tolerances of quality 6 or sometimes 5. The housings, which are more difficult to machine, are usually in quality 7 or sometimes 6 tolerances.

Diameter		Quality	
mm	5	6	7
>3 to 6	5	8	12
>6 to 10	6	9	15
>10 to 18	8	11	18
>18 to 30	9	13	21
>30 to 50	11	16	25
>50 to 80	13	19	30
>80 to 120	15	22	35
>120 to 180	18	25	40
>180 to 250	20	29	46
>250 to 315	23	32	52
>315 to 400	25	36	57
>400 to 500	27	40	63

Fundamental tolerance values (taken from Standard ISO 286).

In certain cases, the shape and taper defects in the chosen tolerance interval are unacceptable because they are detrimental to correct bearing operation. In such cases a smaller tolerance interval must be adopted.



Bearing seats (continued)

Recommended fits

Analycic	Dotontion		Shaft			Housing	
of rotation	principle	Applications	Recommended fits	Examples	Applications	Recommended fits	Examples
The load turns with respect to the outer ring	Inner ring press	Normal loads P < C / 5	j6 / k6	Electric motors Machine tool spindles Pumps Fans Speed reducers	General case	H7 / J7	Electric motors of moderate power Pulleys Machine-tool spindles Transmissions
	fitted on shaft	High	m6 / n6	Traction motors	Ring floats on its seat	G7 / H7	Axial displacement required (expansion or adjustment)
		P > C / 5	1107 90	reducer, compressors	Cylindrical and tapered roller bearings	M7 / P7	
The load turns with respect to the inner ring	Outer ring press	General case	g6 / h6	ldler pulleys Tensioners Wheels	Normal loads P < C / 5	M7 / N7	ldler pulleys Tensioners Wheels
	fitted in housing	Ring floats on its seat	f6 / g6	Axial displacement required (expansion or adjustment)	Very high loads High loads with impacts P > C / 5	N7 / P7	Railway equipment Heavy-duty roller bearings
Other cases		Purely axial loads	h6 / j6	Bearings and thrust bearings	Purely axial loads	G7 / H7	Bearings and thrust
		Adapter sleeves	h9	Agricultural Equipment	anidi iudus		bearings

Different choices can be made to take into account various construction and operating factors: for example, if an assembly is subject to vibration and impact, tighter fits must be considered.

Moreover, the type of mounting and the installation procedure can demand different fits. For example, the fit adopted for light alloy housings is usually tighter than those normally specified, to compensate for the differential thermal expansion.

The following tables illustrate the fits used most frequently in the mounting of bearings. Example for an SNR 6305 ball bearing (25x62x17)

Bearing/housing fit



Shaft/bearing fit





99

Bearing seats (continued)

Value of tolerances and fits

The tables on the following pages indicate:

- the tolerance (in µm) on the bore or outside diameter of the bearing (Standard ISO 492)
- the tolerance (in µm) on the seat diameter according to the chosen fit. (Standard ISO 286)
- the differences (in μ m) between the respective diameters of the bearing and its seat:
 - Theoretical values calculated from the extreme bearing and seat tolerance values
 - Mean values
 - Probable values calculated using the Gauss distribution law. (with a probability of 99.7%) from the formula:

Probable tol. = $[(Bearing tol.)^2 + (Seat tol.)^2]^{1/2}$

These tables concern all types of bearings except tapered roller bearings. For tapered roller bearings, use the same calculation procedure but with their specific tolerances.



In practice, one generally only considers the probable tolerance (the risks of error being limited to 0.3%) to determine a realistic value for the probable clearance tolerance of a bearing after fitting.

Example

SNR 6305 bearing (25 mm bore). Fit on shaft k5.

	Tolera mini	ince maxi	Mean value	Tolerance interval		
Bearing bore	-10	0	-5	10		
Shaft tolerance	+2	+11	+6.5	9		

• theoretical mean interference	=	- (shaft mean val bearing mean val.) = - [6,5 - (-5)] = -11,5
• theoretical max. interference	=	- (shaft max. val bearing min. val.) = - [11- (-10)] = -21
• theoretical min. interference	=	- (shaft min. val bearing max. val.) = - (2-0) = -2
• probable tolerance	=	[(bearing tol. interval) ² + (shaft tol. interval) ²] ^{1/2} = $(10^2 + 9^2)^{1/2} = 13$
• probable max. interference	=	theoretical mean interference - probable tolerance /2
	=	-11,5 - 6,5 = -18
• probable min. interference	=	theoretical mean interference + probable tolerance /2
	=	-11,5 + 6,5 = -5



Fits on shaft for normal class bearings (all bearings except tapered roller bearings)

S	HAFT											
Nom	inal dia of sha (mm)	ameer ft	Bearing bore toleran (µm)	ce Fits	f5	f6	g5	g6	h5	h6	j5	j6
3	<d≤< td=""><td>6</td><td>-8 0</td><td>Shaft tolerances in µm</td><td>-15 -10</td><td>-18 -10</td><td>-9 -4</td><td>-12 -4</td><td>-5 0</td><td>-8 0</td><td>1 +4</td><td>-1 +7</td></d≤<>	6	-8 0	Shaft tolerances in µm	-15 -10	-18 -10	-9 -4	-12 -4	-5 0	-8 0	1 +4	-1 +7
				Mean Probable difference in diameters	+8.5	+10 +15.5 +4.5	-2.5	+4 +9.5 -1.5	-1.5 +3 -6	0 +5.5 -5.5	-5.5	-7
6	<d≤< td=""><td>10</td><td>-8 0</td><td>Shaft tolerances in µm</td><td>-19 -13</td><td>-22 -13</td><td>-11 -5</td><td>-14 -5</td><td>-6 0</td><td>-9 0</td><td>-2 +4</td><td>-2 +7</td></d≤<>	10	-8 0	Shaft tolerances in µm	-19 -13	-22 -13	-11 -5	-14 -5	-6 0	-9 0	-2 +4	-2 +7
				Mean Probable difference in diameters	+12	+13.5	+4	+5.5	-1	+0.5	-5	-6.5
10	<d≤< td=""><td>18</td><td>-8 0</td><td>Shaft tolerances in um</td><td>-24 -16</td><td>-27 -16</td><td>-14 -6</td><td>-17 -6</td><td>-8 0</td><td>-11 0</td><td>-3 +5</td><td>-3 +8</td></d≤<>	18	-8 0	Shaft tolerances in um	-24 -16	-27 -16	-14 -6	-17 -6	-8 0	-11 0	-3 +5	-3 +8
				Mean Dashabla differentera	+16	+17.5	6+	+7.5	0	+1.5	-5	-6.5
18	cd-	30	-10 0	Shaft tolerances in um	+21.5+10.5	+24.5 +10.5	+11.5 +0.5	+14.5 +0.5	+0.0 -0.0	+8.0 -0.0	+0.5 -10.5	+0.5 -13.5
10	<us< td=""><td>50</td><td>-10 0</td><td>Mean</td><td>+19.5</td><td>+21.5</td><td>+6.5</td><td>+8.5</td><td>-0.5</td><td>+1.5</td><td>-5.5</td><td>-7.5</td></us<>	50	-10 0	Mean	+19.5	+21.5	+6.5	+8.5	-0.5	+1.5	-5.5	-7.5
00		50	10 0	Probable difference in diameters	+26 +13	+30 +13	+13 0	+17 0	+6 -7	+10 -7	+1 -12	+1 -16
30	<0≤	50	-12 0	Snatt tolerances in µm Mean	-36 -25 +24.5	-41 -25	-20 -9 +8.5	-25 -9 +11	-11 0	-16 U +2	-5 +6	-5 +11
				Probable difference in diameters	+32.5+16.5	+37 +17	+16.5 +0.5	+21 +1	+7.5 -8.5	+12 -8	+1.5 -14.5	+1 -19
50	<d≤< td=""><td>65</td><td>-15 0</td><td>Shaft tolerances in µm Mean</td><td>-43 -30</td><td>-49 -30</td><td>-23 -10</td><td>-29 -10</td><td>-13 0</td><td>-19 0 +2</td><td>-7 +6</td><td>-7 +12</td></d≤<>	65	-15 0	Shaft tolerances in µm Mean	-43 -30	-49 -30	-23 -10	-29 -10	-13 0	-19 0 +2	-7 +6	-7 +12
				Probable difference in diameters	+39 +19	+44 +20	+19 -1	+24 0	+9 -11	+14 -10	+3 -17	+2 -22
65	<d≤< td=""><td>80</td><td>-15 0</td><td>Shaft tolerances in µm</td><td>-43 -30</td><td>-49 -30</td><td>-23 -10</td><td>-29 -10</td><td>-13 0</td><td>-19 0</td><td>-7 +6</td><td>-7 +12</td></d≤<>	80	-15 0	Shaft tolerances in µm	-43 -30	-49 -30	-23 -10	-29 -10	-13 0	-19 0	-7 +6	-7 +12
				Probable difference in diameters	+39 +19	+44 +20	+19 -1	+24 0	+9 -11	+14 -10	+3 -17	+2 -22
80	<d≤< td=""><td>100</td><td>-20 0</td><td>Shaft tolerances in µm</td><td>-51 -36</td><td>-58 -36</td><td>-27 -12</td><td>-34 -12</td><td>-15 0</td><td>-22 0</td><td>-9 +6</td><td>-9 +13</td></d≤<>	100	-20 0	Shaft tolerances in µm	-51 -36	-58 -36	-27 -12	-34 -12	-15 0	-22 0	-9 +6	-9 +13
				Mean Probable difference in diameters	+33.5 +46 +21	+37 +52 +22	+9.5 +22 -3	+13 +28 -2	-2.5 +10 -15	+1 +16 -14	-8.5 +4 -21	-12 +3 -27
100	<d≤< td=""><td>120</td><td>-20 0</td><td>Shaft tolerances in µm</td><td>-51 -36</td><td>-58 -36</td><td>-27 -12</td><td>-34 -12</td><td>-15 0</td><td>-22 0</td><td>-9 +6</td><td>-9 +13</td></d≤<>	120	-20 0	Shaft tolerances in µm	-51 -36	-58 -36	-27 -12	-34 -12	-15 0	-22 0	-9 +6	-9 +13
				Mean Probable difference in diameters	+33.5	+37	+9.5	+13	-2.5 ±10 -15	+1 +16 -14	-8.5 +4 -21	-12
120	<d≤< td=""><td>140</td><td>-25 0</td><td>Shaft tolerances in um</td><td>-61 -43</td><td>-68 -43</td><td>-32 -14</td><td>-39 -14</td><td>-18 0</td><td>-25 0</td><td>-11 +7</td><td>-11 +14</td></d≤<>	140	-25 0	Shaft tolerances in um	-61 -43	-68 -43	-32 -14	-39 -14	-18 0	-25 0	-11 +7	-11 +14
				Mean Drobable difference in diameters	+39.5	+43	+10.5	+14	-3.5	0	-10.5	-14
140	cde.	160	-25 0	Shaft tolerances in um	+00 +24	+60.5+25.5	+20 -0	+31.0 -3.0	+12 -19	+17.5 -17.5	+0 -20	+4 -32
140	\u_3	100	20 0	Mean	+39.5	+43	+10.5	+14	-3.5	0	-10.5	-14
160	ad a	100	25 0	Probable difference in diameters	+55 +24	+60.5+25.5	+26 -5	+31.5 +3.5	+12 -19	+17.5 -17.5	+5 -26	+4 -32
100	<us< td=""><td>100</td><td>-23 0</td><td>Mean</td><td>+39.5</td><td>+43</td><td>+10.5</td><td>+14</td><td>-10 0</td><td>-23 0</td><td>-10.5</td><td>-14</td></us<>	100	-23 0	Mean	+39.5	+43	+10.5	+14	-10 0	-23 0	-10.5	-14
				Probable difference in diameters	+55 +24	+60.5+25.5	+26 -5	+31.5 -3.5	+12 -19	+17.5 -17.5	+5 -26	+4 -32
180	<0≤	200	-30 0	Shaft tolerances in µm Mean	-/0 -50	-/9 -50	-35 -15 +10	-44 -15	-20 0	-29 0	-13 +/	-13 +16 -16.5
				Probable difference in diameters	+63 +27	+70.5+28.5	+28 -8	+35.5 -6.5	+13 -23	+20.5 -21.5	+6 -30	+4.5 -37.5
200	<d≤< td=""><td>225</td><td>-30 0</td><td>Shaft tolerances in µm Mean</td><td>-70 -50</td><td>-79 -50</td><td>-35 -15</td><td>-44 -15</td><td>-20 0</td><td>-29 0</td><td>-13 +7</td><td>-13 +16</td></d≤<>	225	-30 0	Shaft tolerances in µm Mean	-70 -50	-79 -50	-35 -15	-44 -15	-20 0	-29 0	-13 +7	-13 +16
				Probable difference in diameters	+63 +27	+70.5+28.5	+28 -8	+35.5 -6.5	+13 -23	+20.5 -21.5	+6 -30	+4.5 -37.5
225	<d≤< td=""><td>250</td><td>-30 0</td><td>Shaft tolerances in µm</td><td>-70 -50</td><td>-79 -50</td><td>-35 -15</td><td>-44 -15</td><td>-20 0</td><td>-29 0</td><td>-13 +7</td><td>-13 +16</td></d≤<>	250	-30 0	Shaft tolerances in µm	-70 -50	-79 -50	-35 -15	-44 -15	-20 0	-29 0	-13 +7	-13 +16
				Probable difference in diameters	+45 +63 +27	+49.5 +70.5+28.5	+10 +28 -8	+14.5 +35.5 -6.5	-5 +13 -23	-0.5 +20.5 -21.5	-12 +6 -30	-16.5 +4.5 -37.5
250	<d≤< td=""><td>280</td><td>-35 0</td><td>Shaft tolerances in µm</td><td>-79 -56</td><td>-88 -56</td><td>-40 -17</td><td>-49 -17</td><td>-23 0</td><td>-32 0</td><td>-16 +7</td><td>-16 +16</td></d≤<>	280	-35 0	Shaft tolerances in µm	-79 -56	-88 -56	-40 -17	-49 -17	-23 0	-32 0	-16 +7	-16 +16
				Mean Probable difference in diameters	+50 +71 +29	+54.5 +78 +31	+11 +32 -10	+15.5 +39 -8	-6 +15 -27	-1.5 +22 -25	-13 +8 -34	-17.5 +6 -41
280	<d≤< td=""><td>315</td><td>-35 0</td><td>Shaft tolerances in µm</td><td>-79 -56</td><td>-88 -56</td><td>-40 -17</td><td>-49 -17</td><td>-23 0</td><td>-32 0</td><td>-16 +7</td><td>-16 +16</td></d≤<>	315	-35 0	Shaft tolerances in µm	-79 -56	-88 -56	-40 -17	-49 -17	-23 0	-32 0	-16 +7	-16 +16
				Mean Probable difference in diameters	+50	+54.5	+11	+15.5	-6	-1.5	-13	-17.5
315	1<</td <td>400</td> <td>-40 0</td> <td>Shaft tolerances in um</td> <td>+/1 +29</td> <td>+10 +31</td> <td>+32 -10</td> <td>+39 -0</td> <td>+10 -21</td> <td>+22 -23</td> <td>+0 -34</td> <td>+0 -41</td>	400	-40 0	Shaft tolerances in um	+/1 +29	+10 +31	+32 -10	+39 -0	+10 -21	+22 -23	+0 -34	+0 -41
010	~u.a	400	40 0	Mean	+57	+62.5	+13	+18.5	-5	-0.5	-12	-17.5
400	. el .	500	45 0	Probable difference in diameters	+/9 +35	+88 +3/	+35 -9	+44 -/	+1/ -2/	+26 -25	+10 -34	+8 -43
400	<0≤	500	-45 0	Mean	-90 -08	+70.5	+16	+22.5	-2/ 0	+2.5	-20 +/	-20 +20
				Probable difference in diameters	+86 +42	+97 +44	+38 -6	+49 -4	+18 -26	+29 -24	+11 -33	+9 -44
500	<d≤< td=""><td>630</td><td>-50 0</td><td>Shaft tolerances in µm Mean</td><td></td><td>-120 -76 +80.5</td><td></td><td>+26.5</td><td>-32 0</td><td>-44 0 +4.5</td><td></td><td></td></d≤<>	630	-50 0	Shaft tolerances in µm Mean		-120 -76 +80.5		+26.5	-32 0	-44 0 +4.5		
				Probable difference in diameters		+109 +52		+55 -2	+22 -25	+33 -24		
630	<d≤< td=""><td>800</td><td>-75 0</td><td>Shaft tolerances in µm</td><td></td><td>-130 -80</td><td></td><td>-74 -24</td><td>-36 0</td><td>-50 0</td><td></td><td></td></d≤<>	800	-75 0	Shaft tolerances in µm		-130 -80		-74 -24	-36 0	-50 0		
				Probable difference in diameters		+07.5		+62 +1	+26 -25	+38 -23		

1. A negative value denotes an interference fit and a positive value a loose fit

2. The probable fit values are calculated on the assumption that the statistical distribution of the dimensions within the tolerances follows a "normal" law (Gauss distribution law) 3. Bearing tolerances and fits: values in microns (μm) 4. ▼ The most common fits

Fits on shaft for normal class bearings (all bearings except tapered roller bearings)

SHAF	FT						$\mathbf{\nabla}$				
Nom diameter (m	ninal r of shaft nm)	Bearing bor tolerance (µm)	Fits	k5	k6	m5	m6	n5	n6	p5	p6
3 <0	d≤ 6	-8 0	Shaft tolerances in µm	+1 +6	+1 +9	+4 +9	+4 +12	+8 +13	+8 +16	+12 +17	+12 +20
			Probable difference in diameters	-3 -12	-3.5 -14.5	-6 -15	-6.5 -17.5	-10 -19	-10.5-21.5	-14 -23	-14.5-25.5
6 <0	d≤ 10	-8 0	Shaft tolerances in µm	+1 +7	+1 +10	+8 +12	+6 +15	+10 +16	+10 +19	+15 +21	+15 +24
			Mean Probable difference in diameters	-3 -13	-9.5 -3.5 -15.5	-13 -8 -18	-14.5	-12 -22	-18.5	-17 -27	-23.5 -17.5-29.5
10 <0	d≤ 18	-8 0	Shaft tolerances in µm	+1 +9	+1 +12	+7 +15	+7 +18	+12 +20	+12 +23	+18 +26	+18 +29
			Mean Probable difference in diameters	-9 -3.5 -14.5	-10.5	-15 -9.5 -20.5	-16.5 -9.5 -23.5	-20	-21.5 -14.5-28.5	-26 -20.5-31.5	-27.5 -20.5-34.5
18 <0	d≤ 30	-10 0	Shaft tolerances in µm	+2 +11	+2 +15	+8 +17	+8 +21	+15 +24	+15 +28	+22 +31	+22 +35
			Mean Probable difference in diameters	-11.5 -5 -18	-13.5 -5 -22	-17.5 -11 -24	-19.5 -11 -28	-24.5 -18 -31	-26.5 -18 -35	-31.5 -25 -38	-33.5 -25 -42
30 <0	d≤ 50	-12 0	Shaft tolerances in µm	+2 +13	+2 +18	+9 +20	+9 +25	+17 +28	+17 +33	+26 +37	+26 +42
			Mean Probable difference in diameters	-13.5	-16	-20.5	-23	-28.5	-31	-37.5	-40
50 <0	d≤ 65	-15 0	Shaft tolerances in µm	+2 +15	+2 +21	+11 +24	+11 +30	+20 +33	+20 +39	+32 +45	+32 +51
			Mean Deskakla difference in diservature	-16	-19	-25	-28	-34	-37	-46	-49
65 <(08 ~h	-15 0	Shaft tolerances in um	-0 -20	-/ -31	-10 -30	-10 -40	+20 +33	+20 +30	-30 -30	-37 -01
00 \(u <u>a</u> 00	10 0	Mean	-16	-19	-25	-28	-34	-37	-46	-49
<u> </u>	da 100	20 0	Probable difference in diameters	-6 -26	-7 -31	-15 -35	-16 -40	-24 -44	-25 -49	-36 -56	-3/ -61
00 <1	us 100	-20 0	Mean	-20.5	-24	-30.5	-34	-40.5	-44	-54.5	-58
100	4 100	00 0	Probable difference in diameters	-8 -33	-9 -39	-18 -43	-19 -49	-28 -53	-29 -59	-42 -67	-43 -73
100 <0	0≤ 120	-20 0	Mean	-20.5	+3 +25	-30.5	-34	+23 +38	+23 +45	+37 +52	+37 +59 -58
100			Probable difference in diameters	-8 -33	-9 -39	-18 -43	-19 -49	-28 -53	-29 -59	-42 -67	-43 -73
120 <0	0≤ 140	-25 0	Mean	+3 +21	+3 +28	+15 +33 -36.5	+15 +40	+27 +45	+27 +52	+43 +61 -64.5	+43 +68 -68
			Probable difference in diameters	-9 -40	-10.5-45.5	-21 -52	-22.5-57.5	-33 -64	-34.5-69.5	-49 -80	-50.5-85.5
140 <0	d≤ 160	-25 0	Shaft tolerances in µm Mean	+3 +21	+3 +28	+15 +33	+15 +40	+27 +45	+27 +52	+43 +61	+43 +68
			Probable difference in diameters	-9 -40	-10.5-45.5	-21 -52	-22.5-57.5	-33 -64	-34.5-69.5	-49 -80	-50.5-85.5
160 <d< td=""><td>l≤ 180</td><td>-25 0</td><td>Shaft tolerances in µm Mean</td><td>+3 +21</td><td>+3 +28</td><td>+15 +33</td><td>+15 +40</td><td>+27 +45</td><td>+27 +52</td><td>+43 +61</td><td>+43 +68 -68</td></d<>	l≤ 180	-25 0	Shaft tolerances in µm Mean	+3 +21	+3 +28	+15 +33	+15 +40	+27 +45	+27 +52	+43 +61	+43 +68 -68
			Probable difference in diameters	-9 -40	-10.5-45.5	-21 -52	-22.5-57.5	-33 -64	-34.5-69.5	-49 -80	-50.5-85.5
180 <d< td=""><td>i≤ 200</td><td>-30 0</td><td>Shaft tolerances in µm Mean</td><td>+4 +24</td><td>+4 +33</td><td>+17 +37</td><td>+17 +46</td><td>+31 +51</td><td>+31 +60</td><td>+50 +70</td><td>+50 +79</td></d<>	i≤ 200	-30 0	Shaft tolerances in µm Mean	+4 +24	+4 +33	+17 +37	+17 +46	+31 +51	+31 +60	+50 +70	+50 +79
			Probable difference in diameters	-11 -47	-12.5 -54.5	-24 -60	-25.5-67.5	-38 -74	-39.5-81.5	-57 -93	-58.5-100.5
200 <d< td=""><td>l≤ 225</td><td>-30 0</td><td>Shaft tolerances in µm Mean</td><td>+4 +24</td><td>+4 +33</td><td>+17 +37</td><td>+17 +46</td><td>+31 +51</td><td>+31 +60</td><td>+50 +70</td><td>+50 +79</td></d<>	l≤ 225	-30 0	Shaft tolerances in µm Mean	+4 +24	+4 +33	+17 +37	+17 +46	+31 +51	+31 +60	+50 +70	+50 +79
			Probable difference in diameters	-11 -47	-12.5 -54.5	-24 -60 -	25.5 -67.5	-38 -74	39.5 -81.5	-57 -93	58.5-100.5
225 <d< td=""><td>l≤ 250</td><td>-30 0</td><td>Shaft tolerances in µm Mean</td><td>+4 +24</td><td>+4 +33</td><td>+17 +37</td><td>+17 +46</td><td>+31 +51</td><td>+31 +60</td><td>+50 +70</td><td>+50 +79</td></d<>	l≤ 250	-30 0	Shaft tolerances in µm Mean	+4 +24	+4 +33	+17 +37	+17 +46	+31 +51	+31 +60	+50 +70	+50 +79
			Probable difference in diameters	-11 -47	-12.5-54.5	-24 -60	-25.5-67.5	-38 -74	-39.5-81.5	-57 -93	-58.5-100.5
250 <d< td=""><td>l≤ 280</td><td>-35 0</td><td>Shaft tolerances in µm</td><td>+4 +27</td><td>+4 +36</td><td>+20 +43</td><td>+20 +52</td><td>+34 +57</td><td>+34 +66</td><td>+56 +79</td><td>+56 +88</td></d<>	l≤ 280	-35 0	Shaft tolerances in µm	+4 +27	+4 +36	+20 +43	+20 +52	+34 +57	+34 +66	+56 +79	+56 +88
			Probable difference in diameters	-12 -54	-14 -61	-28 -70	-30 -77	-42 -84	-44 -91	-64 -106	-66 -113
280 <d< td=""><td>l≤ 315</td><td>-35 0</td><td>Shaft tolerances in µm</td><td>+4 +27</td><td>+4 +36</td><td>+20 +43</td><td>+20 +52</td><td>+34 +57</td><td>+34 +66</td><td>+56 +79</td><td>+56 +88</td></d<>	l≤ 315	-35 0	Shaft tolerances in µm	+4 +27	+4 +36	+20 +43	+20 +52	+34 +57	+34 +66	+56 +79	+56 +88
			Probable difference in diameters	-12 -54	-14 -61	-28 -70	-30 -77	-42 -84	-44 -91	-64 -106	-66 -113
315 <d< td=""><td>l≤ 400</td><td>-40 0</td><td>Shaft tolerances in µm</td><td>+4 +29</td><td>+4 +40</td><td>+21 +46</td><td>+21 +57</td><td>+37 +62</td><td>+37 +73</td><td>+62 +87</td><td>+62 +98</td></d<>	l≤ 400	-40 0	Shaft tolerances in µm	+4 +29	+4 +40	+21 +46	+21 +57	+37 +62	+37 +73	+62 +87	+62 +98
			Probable difference in diameters	-34	-39.5 -14 -65	-29 -73	-30.5	-45 -89	-12.5	-92 -70 -114	-97.5
400 <d< td=""><td>l≤ 500</td><td>-45 0</td><td>Shaft tolerances in µm</td><td>+5 +32</td><td>+5 +45</td><td>+23 +50</td><td>+23 +63</td><td>+40 +67</td><td>+40 +80</td><td>+68 +95</td><td>+68 +108</td></d<>	l≤ 500	-45 0	Shaft tolerances in µm	+5 +32	+5 +45	+23 +50	+23 +63	+40 +67	+40 +80	+68 +95	+68 +108
			Probable difference in diameters	-36	-42.5 -16 -69	-32 -76	-60.5 -34 -87	-49 -93	-77.5	-99 -77 -121	-105.5
500 <d< td=""><td>l≤ 630</td><td>-50 0</td><td>Shaft tolerances in µm</td><td></td><td>0 +44</td><td></td><td>+26 +70</td><td></td><td>+44 +88</td><td></td><td>+78 +122</td></d<>	l≤ 630	-50 0	Shaft tolerances in µm		0 +44		+26 +70		+44 +88		+78 +122
			Probable difference in diameters		-39.5 -11 -68		-65.5 -37 -94		-83.5 -55 -112		-117.5 -89 -146
630 <d< td=""><td>l≤ 800</td><td>-75 0</td><td>Shaft tolerances in µm</td><td></td><td>0 +50</td><td></td><td>+30 +80</td><td></td><td>+50 +100</td><td></td><td>+88 +138</td></d<>	l≤ 800	-75 0	Shaft tolerances in µm		0 +50		+30 +80		+50 +100		+88 +138
			Mean Probable difference in diameters		-42.5 -12 -73		-/2.5 -42 -103		-92.5 -62 -123		-130.5 -100 -161

1. A negative value denotes an interference fit and a positive value a loose fit 2. The probable fit values are calculated on the assumption that the statistical distribution of the dimensions within the tolerances follows a "normal" law (Gauss distribution law) 3. Bearing tolerances and fits: values in microns (µm) 4. ▼ The most common fits

103



Fits in the housings for normal class bearings (all bearings except tapered roller bearings)

HOUSING						$\mathbf{\nabla}$		$\mathbf{\nabla}$		
Nominal diameter of housing (mm)	Tolerance on outside diameter (µm)	Fits	G6	G7	H6	H7	J6	J7	K6	K7
10 <d≤ 18<="" td=""><td>-8 0</td><td>Housing tolerance</td><td>+6 +17</td><td>+6 +24</td><td>0 +11</td><td>0 +18</td><td>-5 +6</td><td>-8 +10</td><td>-9 +2</td><td>-12 +6</td></d≤>	-8 0	Housing tolerance	+6 +17	+6 +24	0 +11	0 +18	-5 +6	-8 +10	-9 +2	-12 +6
		Mean Probable difference in diameters	+15.5 +22.5 +8.5	+19 +29 +9	+9.5 +16.5 +2.5	+13 +23 +3	+4.5 +11.5 -2.5	+5 +15 -5	+0.5 +7.5 -6.5	+1 +11 -9
18 <d≤ 30<="" td=""><td>-9 0</td><td>Housing tolerance</td><td>+7 +20</td><td>+7 +28</td><td>0 +13</td><td>0 +21</td><td>-5 +8</td><td>-9 +12</td><td>-11 +2</td><td>-15 +6</td></d≤>	-9 0	Housing tolerance	+7 +20	+7 +28	0 +13	0 +21	-5 +8	-9 +12	-11 +2	-15 +6
		Mean Probable difference in diameters	+18 +26 +10	+22 +33.5 +10.5	+11 +19 +3	+15 +26.5 +3.5	+b +14 -2	+6 +17.5 -5.5	+8 -8	+11.5 -11.5
30 <d≤ 50<="" td=""><td>-11 0</td><td>Housing tolerance</td><td>+9 +25</td><td>+9 +34</td><td>0 +16</td><td>0 +25</td><td>-6 +10</td><td>-11 +14</td><td>-13 +3</td><td>-18 +7</td></d≤>	-11 0	Housing tolerance	+9 +25	+9 +34	0 +16	0 +25	-6 +10	-11 +14	-13 +3	-18 +7
		Mean Probable difference in diameters	+22.5 +32 +13	+27 +40.5 +13.5	+13.5 +23 +4	+18 +31.5 +4.5	+17 -2	+20.5 -6.5	+0.5	+13.5 -13.5
50 <d≤ 65<="" td=""><td>-13 0</td><td>Housing tolerance</td><td>+10 +29</td><td>+10 +40</td><td>0 +19</td><td>0 +30</td><td>-6 +13</td><td>-12 +18</td><td>-15 +4</td><td>-21 +9</td></d≤>	-13 0	Housing tolerance	+10 +29	+10 +40	0 +19	0 +30	-6 +13	-12 +18	-15 +4	-21 +9
		Mean Probable difference in diameters	+26 +37.5 +14.5	+31.5 +48 +15	+16 +27.5 +4.5	+21.5 +38 +5	+10 +21.5 -1.5	+9.5	+1 +12.5 -10.5	+0.5 +17 -16
65 <d≤ 80<="" td=""><td>-13 0</td><td>Housing tolerance</td><td>+10 +29</td><td>+10 +40</td><td>0 +19</td><td>0 + 30</td><td>-6 +13</td><td>-12 +18</td><td>-15 +4</td><td>-21 +9</td></d≤>	-13 0	Housing tolerance	+10 +29	+10 +40	0 +19	0 + 30	-6 +13	-12 +18	-15 +4	-21 +9
		Mean Probable difference in diameters	+26 +37.5 +14.5	+31.5 +48 +15	+16 +27.5 +4.5	+21.5 +38 +5	+10 +21.5 -1.5	+9.5 +26 -7	+1 +12.5 -10.5	+0.5 +17 -16
80 <d≤ 100<="" td=""><td>-15 0</td><td>Housing tolerance</td><td>+12 +34</td><td>+12 +47</td><td>0 +22</td><td>0 +35</td><td>-6 +16</td><td>-13 +22</td><td>-18 +4</td><td>-25 +10</td></d≤>	-15 0	Housing tolerance	+12 +34	+12 +47	0 +22	0 +35	-6 +16	-13 +22	-18 +4	-25 +10
		Mean Probable difference in diameters	+30.5	+37	+18.5	+25	+12.5	+12	+0.5	0 ±19 -19
100 <d≤ 120<="" td=""><td>-15 0</td><td>Housing tolerance</td><td>+12 +34</td><td>+12 +47</td><td>0 +22</td><td>0 +35</td><td>-6 +16</td><td>-13 +22</td><td>-18 +4</td><td>-25 +10</td></d≤>	-15 0	Housing tolerance	+12 +34	+12 +47	0 +22	0 +35	-6 +16	-13 +22	-18 +4	-25 +10
		Mean Prohable difference in diameters	+30.5	+37	+18.5	+25	+12.5	+12	+0.5	0
120 <d≤ 140<="" td=""><td>-18 0</td><td>Housing tolerance</td><td>+14 +39</td><td>+14 +54</td><td>+ 32 + 5 0 + 25</td><td>0 +40</td><td>-7 +18</td><td>-14 +26</td><td>-21 +4</td><td>-28 +12</td></d≤>	-18 0	Housing tolerance	+14 +39	+14 +54	+ 32 + 5 0 + 25	0 +40	-7 +18	-14 +26	-21 +4	-28 +12
		Mean Prohable difference in diameters	+35.5	+43 +65 +21	+21.5	+29 +51 +7	+14.5	+15+37-7	+0.5	+1 +23 -21
140 <d≤ 150<="" td=""><td>-18 0</td><td>Housing tolerance</td><td>+14 +39</td><td>+14 +54</td><td>0 +25</td><td>0 +40</td><td>-7 +18</td><td>-14 +26</td><td>-21 +4</td><td>-28 +12</td></d≤>	-18 0	Housing tolerance	+14 +39	+14 +54	0 +25	0 +40	-7 +18	-14 +26	-21 +4	-28 +12
		Mean Probable difference in diameters	+35.5	+43+65+21	+21.5	+29 +51 +7	+14.5	+15+37-7	+0.5	+1 +23 -21
150 <d≤ 160<="" td=""><td>-25 0</td><td>Housing tolerance</td><td>+14 +39</td><td>+14 +54</td><td>0 +25</td><td>0 +40</td><td>-7 +18</td><td>-14 +26</td><td>-21 +4</td><td>-28 +12</td></d≤>	-25 0	Housing tolerance	+14 +39	+14 +54	0 +25	0 +40	-7 +18	-14 +26	-21 +4	-28 +12
		Mean Probable difference in diameters	+39 +56.5 +21.5	+46.5	+25 +42.5 +7.5	+32.5	+18 +35.5 +0.5	+18.5	+4 +21.5 -13.5	+4.5
160 <d≤ 180<="" td=""><td>-25 0</td><td>Housing tolerance</td><td>+14 +39</td><td>+14 +54</td><td>0 +25</td><td>0 +40</td><td>-7 +18</td><td>-14 +26</td><td>-21 +4</td><td>-28 +12</td></d≤>	-25 0	Housing tolerance	+14 +39	+14 +54	0 +25	0 +40	-7 +18	-14 +26	-21 +4	-28 +12
		Mean Probable difference in diameters	+39	+46.5	+25	+32.5	+18	+18.5	+4	+4.5
180 <d≤ 200<="" td=""><td>-30 0</td><td>Housing tolerance</td><td>+15 +44</td><td>+15 +61</td><td>0 +29</td><td>+30 +3 0 +46</td><td>-7 +22</td><td>-16 +30</td><td>-24 +5</td><td>-33 +13</td></d≤>	-30 0	Housing tolerance	+15 +44	+15 +61	0 +29	+30 +3 0 +46	-7 +22	-16 +30	-24 +5	-33 +13
		Mean Probable difference in diameters	+44.5	+53	+29.5	+38	+22.5	+22	+5.5	+5 +32.5 -22.5
200 <d≤ 225<="" td=""><td>-30 0</td><td>Housing tolerance</td><td>+15 +44</td><td>+15 +61</td><td>0 +29</td><td>0 +46</td><td>-7 +22</td><td>-16 +30</td><td>-24 +5</td><td>-33 +13</td></d≤>	-30 0	Housing tolerance	+15 +44	+15 +61	0 +29	0 +46	-7 +22	-16 +30	-24 +5	-33 +13
		Mean Probable difference in diameters	+44.5	+53	+29.5	+38	+22.5	+22	+5.5	+5
225 <d< 250<="" td=""><td>-30 0</td><td>Housing tolerance</td><td>+15 +44</td><td>+15 +61</td><td>+30.3 +0.3</td><td>0 +46</td><td>-7 +22</td><td>-16 +30</td><td>-24 +5</td><td>+32.5 -22.5</td></d<>	-30 0	Housing tolerance	+15 +44	+15 +61	+30.3 +0.3	0 +46	-7 +22	-16 +30	-24 +5	+32.5 -22.5
220 (02 200		Mean Drahable difference in diameters	+44.5	+53	+29.5	+38	+22.5	+22	+5.5	+5
250 cD- 280	-35 0	Housing tolerance	+00.0 +23.0	+80.5 +25.5	+50.5 +8.5	+00.0 +10.0	+43.5 +1.5	+49.5 -5.5	+20.3 -13.3	+32.5 -22.5
200 (05 200	-00 0	Mean	+50.5	+60.5	+33.5	+43.5	+26.5	+27.5	+6.5	+7.5
000 D 015	05 0	Probable difference in diameters	+74 +27	+92 +29	+57 +10	+75 +12	+50 +3	+59 -4	+30 -17	+39 -24
200 <d< 910<="" td=""><td>-30 0</td><td>Mean</td><td>+17 +49 +50.5</td><td>+17 +69</td><td>+33.5</td><td>+43.5</td><td>+26.5</td><td>+27.5</td><td>+6.5</td><td>+7.5</td></d<>	-30 0	Mean	+17 +49 +50.5	+17 +69	+33.5	+43.5	+26.5	+27.5	+6.5	+7.5
215 (D) 400	40 0	Probable difference in diameters	+74 +27	+92 +29	+57 +10	+75 +12	+50 +3	+59 -4	+30 -17	+39 -24
310 <d≤ 400<="" td=""><td>-40 0</td><td>Mean</td><td>+10 +54</td><td>+10 +73</td><td>+36.5</td><td>+46</td><td>+28.5</td><td>+28</td><td>+6.5</td><td>+6</td></d≤>	-40 0	Mean	+10 +54	+10 +73	+36.5	+46	+28.5	+28	+6.5	+6
400 (D) 500	45 0	Probable difference in diameters	+79 +28	+97 +31	+61 +10	+79 +13	+54 +3	+61 -5	+32 -19	+39 -27
400 <d≤ 200<="" td=""><td>-40 U</td><td>Mean</td><td>+20 +00</td><td>+20 +03</td><td>+37.5</td><td>+49</td><td>+30.5</td><td>-14</td><td>+5.5</td><td>+4</td></d≤>	-40 U	Mean	+20 +00	+20 +03	+37.5	+49	+30.5	-14	+5.5	+4
500 D 000	50 0	Probable difference in diameters	+84 +31	+105 +33	+64 +11	+85 +13	+57 +4	+7 -35	+32 -21	+40 -32
000 <d≤ 630<="" td=""><td>-50 0</td><td>Mean</td><td>+22 +00</td><td>+22 +92 +74.5</td><td>+44 +39.5</td><td>+52.5</td><td></td><td></td><td>-44 0</td><td>-17.5</td></d≤>	-50 0	Mean	+22 +00	+22 +92 +74.5	+44 +39.5	+52.5			-44 0	-17.5
		Probable difference in diameters	+90 +33	+114 +35	+68 +11	+92 +13			+24 -33	+22 -57
630 <d≤ 800<="" td=""><td>-75 0</td><td>Housing tolerance Mean</td><td>+24 +74 +66.5</td><td>+24 +104 +81.5</td><td>U +50 +42.5</td><td>0 +80</td><td></td><td></td><td>-50 0</td><td>-80 0</td></d≤>	-75 0	Housing tolerance Mean	+24 +74 +66.5	+24 +104 +81.5	U +50 +42.5	0 +80			-50 0	-80 0
		Probable difference in diameters	+97 +36	+125 +38	+73 +12	+101 +14			+23 -38	+21 -66
800 <d≤ 1000<="" td=""><td>-100 0</td><td>Housing tolerance Mean</td><td>+26 +82</td><td>+26 +116</td><td>0 +56</td><td>0 +90</td><td></td><td></td><td>-56 0</td><td>-90 0</td></d≤>	-100 0	Housing tolerance Mean	+26 +82	+26 +116	0 +56	0 +90			-56 0	-90 0
		Probable difference in diameters	+105 +38	+137 +40	+79 +12	+111 +14			+23 -44	+21 -76

1. A negative value denotes an interference fit and a positive value a loose fit

2. The probable fit values are calculated on the assumption that the statistical distribution of the dimensions within the tolerances follows a "normal" law (Gauss distribution law)

Bearing tolerances and fits: values in microns (μm)
The most common fits

Fits in the housings for normal class bearings (all bearings except tapered roller bearings)

HOUSING							\checkmark			
Nominal diameter of housing (mm)	Tolerance on outside diameter (µm)	Fits	M6	M7	N6	N7	P6	P7	R6	R7
10 <d≤ 18<="" td=""><td>-8 0</td><td>Housing tolerance</td><td>-15 -4</td><td>-18 0</td><td>-20 -9</td><td>-23 -5</td><td>-26 -15</td><td>-29 -11</td><td>-31 -20</td><td>-34 -16</td></d≤>	-8 0	Housing tolerance	-15 -4	-18 0	-20 -9	-23 -5	-26 -15	-29 -11	-31 -20	-34 -16
		Mean Probable difference in diameters	-5.5 +1.5 -12.5	-5 +5 -15	-10.5 -3.5 -17.5	-10 0 -20	-16.5 -9.5 -23.5	-16 -6 -26	-21.5 -14.5 -28.5	-21 -11 -31
18 <d≤ 30<="" td=""><td>-9 0</td><td>Housing tolerance</td><td>-17 -4</td><td>-21 0</td><td>-24 -11</td><td>-28 -7</td><td>-31 -18</td><td>-35 -14</td><td>-37 -24</td><td>-41 -20</td></d≤>	-9 0	Housing tolerance	-17 -4	-21 0	-24 -11	-28 -7	-31 -18	-35 -14	-37 -24	-41 -20
		Mean Probable difference in diameters	-6 +2 -14	-6 +5.5 -17.5	-13 -5 -21	-13 -1.5 -24.5	-20 -12 -28	-20 -8.5 -31.5	-26 -18 -34	-26 -14.5 -37.5
30 <d≤ 50<="" td=""><td>-11 0</td><td>Housing tolerance</td><td>-20 -4</td><td>-25 0</td><td>-28 -12</td><td>-33 -8</td><td>-37 -21</td><td>-42 -17</td><td>-45 -29</td><td>-50 -25</td></d≤>	-11 0	Housing tolerance	-20 -4	-25 0	-28 -12	-33 -8	-37 -21	-42 -17	-45 -29	-50 -25
		Mean Probable difference in diameters	-6.5 +3 -16	-7 +6.5 -20.5	-14.5 -5 -24	-15 -1.5 -28.5	-23.5 -14 -33	-24 -10.5 -37.5	-31.5 -22 -41	-32 -18.5 -45.5
50 <d≤ 65<="" td=""><td>-13 0</td><td>Housing tolerance</td><td>-24 -5</td><td>-30 0</td><td>-33 -14</td><td>-39 -9</td><td>-45 -26</td><td>-51 -21</td><td>-54 -35</td><td>-60 -30</td></d≤>	-13 0	Housing tolerance	-24 -5	-30 0	-33 -14	-39 -9	-45 -26	-51 -21	-54 -35	-60 -30
		Mean Probable difference in diameters	-8 +3.5 -19.5	-8.5 +8 -25	-17 -5.5 -28.5	-17.5 -1 -34	-29 -17.5 -40.5	-29.5 -13 -46	-38 -26.5 -49.5	-38.5 -22 -55
65 <d≤ 80<="" td=""><td>-13 0</td><td>Housing tolerance</td><td>-24 -5</td><td>-30 0</td><td>-33 -14</td><td>-39 -9</td><td>-45 -26</td><td>-51 -21</td><td>-56 -37</td><td>-62 -32</td></d≤>	-13 0	Housing tolerance	-24 -5	-30 0	-33 -14	-39 -9	-45 -26	-51 -21	-56 -37	-62 -32
		Mean Probable difference in diameters	-8 +35-195	-8.5 +8 -25	-17	-17.5	-29 -17.5 -40.5	-29.5	-40	-40.5 -24 -57
80 <d≤ 100<="" td=""><td>-15 0</td><td>Housing tolerance</td><td>-28 -6</td><td>-35 0</td><td>-38 -16</td><td>-45 -10</td><td>-52 -30</td><td>-59 -24</td><td>-66 -44</td><td>.73 .38</td></d≤>	-15 0	Housing tolerance	-28 -6	-35 0	-38 -16	-45 -10	-52 -30	-59 -24	-66 -44	.73 .38
		Mean Drahable difference in diameters	-9.5	-10	-19.5	-20	-33.5	-34	-47.5	-48
100 202 120	-15 0	Housing tolerance	-14 -23 -20 E	25 0	20 16	45 10	-20 -41	-10 -00 50 -04	-04 -01	76 41
100 (03 120	10 0	Mean Probable difference in diameters	-20 -0	-10	-19.5	-40 -20	-33.5	-35 -24 -34 15 52	-50.5	-70 -41 -51 22 70
120 <d≤ 140<="" td=""><td>-18 0</td><td>Housing tolerance</td><td>-33 -8</td><td>-40 0</td><td>-0 -33</td><td>-1 -33</td><td>-61 -36</td><td>-68 -28</td><td>-37 -04</td><td>-32 -70</td></d≤>	-18 0	Housing tolerance	-33 -8	-40 0	-0 -33	-1 -33	-61 -36	-68 -28	-37 -04	-32 -70
		Mean Probable difference in diameters	-11.5	-11	-23.5	-23	-39.5	-39	-59.5	-59
140 <d< 150<="" td=""><td>-18 0</td><td>Housing tolerance</td><td>-33 -8</td><td>-40 0</td><td>-45 -20</td><td>-1 -43</td><td>-61 -36</td><td>-68 -28</td><td>-83 -58</td><td>-90 -50</td></d<>	-18 0	Housing tolerance	-33 -8	-40 0	-45 -20	-1 -43	-61 -36	-68 -28	-83 -58	-90 -50
110 (01 100		Mean Probable difference in diameters	-11.5 +4 -27	-11 +11 -33	-23.5	-23	-39.5	-39 -17 -61	-61.5 -46 -77	-61 -39 -83
150 <d≤ 160<="" td=""><td>-25 0</td><td>Housing tolerance</td><td>-33 -8</td><td>-40 0</td><td>-45 -20</td><td>-52 -12</td><td>-61 -36</td><td>-68 -28</td><td>-83 -58</td><td>-90 -50</td></d≤>	-25 0	Housing tolerance	-33 -8	-40 0	-45 -20	-52 -12	-61 -36	-68 -28	-83 -58	-90 -50
		Mean Probable difference in diameters	-8 +9.5 -25.5	-7.5 +16 -31	-20	-19.5 +4 -43	-36 -18.5 -53.5	-35.5 -12 -59	-58 -40.5 -75.5	-57.5 -34 -81
160 <d≤ 180<="" td=""><td>-25 0</td><td>Housing tolerance</td><td>-33 -8</td><td>-40 0</td><td>-45 -20</td><td>-52 -12</td><td>-61 -36</td><td>-68 -28</td><td>-86 -61</td><td>-93 -53</td></d≤>	-25 0	Housing tolerance	-33 -8	-40 0	-45 -20	-52 -12	-61 -36	-68 -28	-86 -61	-93 -53
		Mean Drahabla difference in diameters	-8	-7.5	-20	-19.5	-36	-35.5	-61	-60.5
180 - 0- 200	-30 0	Housing tolerance	+9.5 -25.5	+10 -31	-2.0 -37.0	+4 -43	-18.5 -53.5	-12 -39	-43.5 -/8.5	-37 -84
100 (04 200	00 0	Mean	-7.5	-8	-21.5	-22	-40.5	-41	-67.5	-68
000 D 005	00 0	Probable difference in diameters	+13.5 -28.5	+19.5 -35.5	-0.5 -42.5	+5.5 -49.5	-19.5 -61.5	-13.5 -68.5	-46.5 -88.5	-40.5 -95.5
200 <d≤ 225<="" td=""><td>-30 0</td><td>Mean</td><td>-3/ -0</td><td>-40 0</td><td>-21.5</td><td>-00 -14</td><td>-40.5</td><td>-79 -33</td><td>-70.5</td><td>-109 -03</td></d≤>	-30 0	Mean	-3/ -0	-40 0	-21.5	-00 -14	-40.5	-79 -33	-70.5	-109 -03
		Probable difference in diameters	+13.5 -28.5	+19.5 -35.5	-0.5 -42.5	+5.5 -49.5	-19.5 -61.5	-13.5 -68.5	-49.5 -91.5	-43.5 -98.5
225 <d≤ 250<="" td=""><td>-30 0</td><td>Housing tolerance Mean</td><td>-3/ -8</td><td>-4b U -8</td><td>-51 -22</td><td>-60 -14 -22</td><td>-/0 -41</td><td>-/9 -33</td><td>-104 -75</td><td>-113 -b/ -75</td></d≤>	-30 0	Housing tolerance Mean	-3/ -8	-4b U -8	-51 -22	-60 -14 -22	-/0 -41	-/9 -33	-104 -75	-113 -b/ -75
		Probable difference in diameters	+13.5 -28.5	+19.5 -35.5	-0.5 -42.5	+5.5 -49.5	-19.5 -61.5	-13.5 -68.5	-53.5 -95.5	-47.5 -102.5
250 <d≤ 280<="" td=""><td>-35 0</td><td>Housing tolerance</td><td>-41 -9</td><td>-52 0</td><td>-57 -25</td><td>-66 -14</td><td>-79 -47</td><td>-88 -36</td><td>-117 -85</td><td>-126 -74</td></d≤>	-35 0	Housing tolerance	-41 -9	-52 0	-57 -25	-66 -14	-79 -47	-88 -36	-117 -85	-126 -74
		Probable difference in diameters	+16 -31	+23 -40	-23.5 0 -47	+9 -54	-45.5	-44.5 -13 -76	-60 -107	-02.5 -51 -114
280 <d≤ 315<="" td=""><td>-35 0</td><td>Housing tolerance</td><td>-41 -9</td><td>-52 0</td><td>-57 -25</td><td>-66 -14</td><td>-79 -47</td><td>-88 -36</td><td>-121 -89</td><td>-130 -78</td></d≤>	-35 0	Housing tolerance	-41 -9	-52 0	-57 -25	-66 -14	-79 -47	-88 -36	-121 -89	-130 -78
		Probable difference in diameters	+16 -31	-8.5 +23 -40	-23.5 0 -47	-22.5 +9 -54	-45.5 -22 -69	-44.5 -13 -76	-87.5 -64 -111	-86.5 -55 -118
315 <d≤ 400<="" td=""><td>-40 0</td><td>Housing tolerance</td><td>-46 -10</td><td>-57 0</td><td>-62 -26</td><td>-73 -16</td><td>-87 -51</td><td>-98 -41</td><td></td><td></td></d≤>	-40 0	Housing tolerance	-46 -10	-57 0	-62 -26	-73 -16	-87 -51	-98 -41		
		Mean Probable difference in diameters	-10.5 +15 -36	-11 +22 -44	-26.5 -1 -52	-27 +6 -60	-51.5 -26 -77	-52 -19 -85		
400 <d≤ 500<="" td=""><td>-45 0</td><td>Housing tolerance</td><td>-50 -10</td><td>-63 0</td><td>-67 -27</td><td>-80 -17</td><td>-95 -55</td><td>-108 -45</td><td></td><td></td></d≤>	-45 0	Housing tolerance	-50 -10	-63 0	-67 -27	-80 -17	-95 -55	-108 -45		
		Mean Probable difference in diameters	-12.5 +14 -39	-14 +22 -50	-29.5 -3 -56	-31 +5 -67	-57.5 -31 -84	+25 -23 -95		
500 <d≤ 630<="" td=""><td>-50 0</td><td>Housing tolerance</td><td>-70 -26</td><td>-96 -26</td><td>-88 -44</td><td>-114 -44</td><td>-122 -78</td><td>-148 -78</td><td></td><td></td></d≤>	-50 0	Housing tolerance	-70 -26	-96 -26	-88 -44	-114 -44	-122 -78	-148 -78		
		Mean Probable difference in diameters	-30.5	-43.5	-48.5	-61.5 -22 -101	-82.5 -54 -111	-95.5 -56 -135		
630 <d< 800<="" td=""><td>-75 0</td><td>Housing tolerance</td><td>-80 -30</td><td>-110 -30</td><td>-100 -50</td><td>-130 -50</td><td>-138 -88</td><td>-168 -88</td><td></td><td></td></d<>	-75 0	Housing tolerance	-80 -30	-110 -30	-100 -50	-130 -50	-138 -88	-168 -88		
		Mean	-37.5	-52.5	-57.5	-72.5	-95.5	-110.5		
800 JD 1000	100 0	Probable difference in diameters	-/ -68	-9 -96	-2/ -88	-29 -116	-65 -126	-6/ -154		
000 <d≤ 1000<="" td=""><td>-100 0</td><td>Mousing tolerance Mean</td><td>-90 -34 -44.5</td><td>-124 -34 -61.5</td><td>-112 -56 -66.5</td><td>-146 -56 -83.5</td><td>-156 -100 -110.5</td><td>-190 -100 -127.5</td><td></td><td></td></d≤>	-100 0	Mousing tolerance Mean	-90 -34 -44.5	-124 -34 -61.5	-112 -56 -66.5	-146 -56 -83.5	-156 -100 -110.5	-190 -100 -127.5		
		Probable difference in diameters	-11 -78	-13 -110	-33 -100	-35 -132	-77 -144	-79 -176		

1. A negative value denotes an interference fit and a positive value a loose fit 2. The probable fit values are calculated on the assumption that the statistical distribution of the dimensions within the tolerances follows a "normal" law (Gauss distribution law) 3. Bearing tolerances and fits: values in microns (µm) 4. ▼ The most common fits

SNR



Bearing seats (continued)

Geometry and surface conditions of shaft and housing seats

Shoulder diameters and fillet radii

A contact surface is necessary between the ring and the shoulder to ensure good retention of the bearing.

The sections in this catalog of Standard Bearings specifies:

- the shaft and housing shoulder diameters (D₁ and d₃)
- the shoulder fillet radii (r1)



The fillet radii between the shoulders and the ring seats must be less than the corner radius of the corresponding ring. The values are indicated in the chapter corresponding to each family.





Fillet greater than the bearing corner radius

When a shaft is subjected to high bending stresses, the shoulder must be given a fillet radius that is greater than that of the bearing.

In this case, a chamfered spacer is placed between the shaft shoulder and the bearing ring to give a sufficiently large contact surface.

106



Special corner radius

If the bearing must be fixed close to the shoulder, a special corner radius can be machined on its inner ring.



Elimination of the fillet radius

If there are no particular requirements for the shaft profile and strength, it is possible to make an undercut that facilitates grinding of the seats and ensures in all cases the best contact between the ring and the shoulder.



Removal seat

The bearing is usually removed using an extraction tool whose claws clamp on the part of the ring that protrudes beyond the shoulder. See page 140.

If the mounting configuration does not leave a sufficiently large removal seat, notches can be cut in the shoulder or a washer can be placed between the shoulder and the bearing inner ring. Clamping point for extraction tool claws



Bearing seats (continued)

Tolerances and surface conditions of shaft and housing seats

Shaft



Nominal ins	ide	Tolerances in µm								
diameter of be d (mm)	earing	T1	T2	T3	Ra1	Ra2				
10 <d≤< td=""><td>18</td><td>3</td><td>11</td><td></td><td></td><td></td></d≤<>	18	3	11							
18 <d≤< td=""><td>30</td><td>4</td><td>13</td><td></td><td></td><td></td></d≤<>	30	4	13							
30 <d≤< td=""><td>50</td><td>4</td><td>16</td><td>1.5 L</td><td>≤1</td><td>≤2</td></d≤<>	50	4	16	1.5 L	≤1	≤2				
50 <d≤< td=""><td>80</td><td>5</td><td>19</td><td>Lin</td><td></td><td></td></d≤<>	80	5	19	Lin						
80 <d≤ 1<="" td=""><td>20</td><td>6</td><td>22</td><td>mm</td><td></td><td></td></d≤>	20	6	22	mm						
120 <d< td=""><td></td><td>8</td><td>25</td><td></td><td></td><td></td></d<>		8	25							

Housing



Nominal inside	Tolerances in µm				
diameter of bearing d (mm)	T1	T2	T3	Ra1	Ra2
18 <d≤ 30<="" td=""><td>6</td><td>21</td><td></td><td></td><td></td></d≤>	6	21			
30 <d≤ 50<="" td=""><td>7</td><td>25</td><td>2 L</td><td>≤2</td><td>≤4</td></d≤>	7	25	2 L	≤2	≤4
50 <d≤ 80<="" td=""><td>8</td><td>30</td><td>Lin</td><td></td><td></td></d≤>	8	30	Lin		
80 <d≤ 120<="" td=""><td>10</td><td>35</td><td>mm</td><td></td><td></td></d≤>	10	35	mm		
120 <d< td=""><td>12</td><td>40</td><td></td><td></td><td></td></d<>	12	40			

Radial clearance of radial contact bearings

Residual radial clearance: definition, calculation

The residual radial clearance is the radial clearance of the bearing after installation or in operation. It depends on the internal radial clearance, the fits, the temperatures and the deformations.

The residual clearance must be sufficient to ensure satisfactory operating conditions.

To calculate the residual clearance, it is given an algebraic value. When this value is positive, there is a mechanical clearance, when it is negative there is a preload.

The operating residual clearance of the bearing has a direct influence on its service life and general performance (precision of rotation, noise, etc.). It must therefore be determined as accurately as possible.

→ Ratio of interference effect on clearance

When two parts are assembled together with an interference fit, each part displays a change in diameter after assembly.

The ratio is:

The ratio is calculated using the standard material strength formulae which introduce the crosssectional dimensions of the parts concerned, the E modulus of elasticity and their respective Poisson ratios.

We propose the following approximate ratios for the most common cases:

Bearing element	Seat	Ratio
Inner ring	Solid shaft	t _i ≈ 0.8
	Hollow shaft	$t_i \approx 0.6$
Outer ring	Steel or cast-iron housing Light alloy housing	t _e ≈ 0.7 t _e ≈ 0.5

SNR can provide a precise calculation of the clearance reduction.



Radial clearance of radial contact bearings (continued)

➔ Residual clearance after fitting: J_{rm}

 $J_{rm} = J_0 - t_i \cdot S_i - t_e \cdot S_e$

- Jo Internal radial clearance
- Si Interference of the inner ring on the shaft
- ti Inner ring/shaft effect ratio
- Se Interference of the outer ring in its housing
- te Outer ring/housing effect ratio

Required approximate mean residual clearance after fitting (in mm)

Ball bearings	$J_{rm} = 10^{-3} d^{1/2}$
Cylindrical roller bearings	$J_{rm} = 4 \cdot 10^{-3} d^{1/2}$
Self-aligning ball bearings	$J_{rm} = 2 \cdot 10^{-3} d^{1/2}$
Spherical roller bearings	$J_{rm} = 5 . 10^{-3} d^{1/2}$

Example of calculation of residual clearance and its range using the fits tables of page 102.

Bearing 6305 - bore 25 mm - outside diameter 62 mm

- Solid steel shaft: tolerance k5
- Cast-iron housing: tolerance N6

Mean residual clearance

The fits tables give:

	min	mean	max
Shaft tolerances	+2		+11
Mean theoretical and probable value Si		-11.5	
Probable clearance (+) or interference (-)	-5		-18

	min	mean	max
Housing tolerances	-33		+14
Mean theoretical and probable value Si		-17	
Probable clearance (+) or interference (-)	-5.5		-28.5

Table in previous page gives the respective effect ratios of $t_i = 0.8$ (shaft) and $t_e = 0.7$ (housing).

The mean reduction in clearance is:

R_{jm} = (t_i . S_i) + (t_e . S_e) (only valid if Si<0 and Se<0)

$$R_{im} = (0.8 \text{ x} - 11.5) + (0.7 \text{ x} - 17) = -21 \mu m$$

\blacksquare The minimum initial clearance value must be greater than the mean reduction in clearance ${\sf R}_{\rm im}$

The table in page 156 of initial clearances for this type of bearing shows that a category 4 clearance is necessary (23 to 41 μ m: mean value 32 μ m) to have a satisfactory residual clearance after fitting the bearing:

Mean residual clearance:

J_{rm} = 32 - 21 = 11 μm

The definition of the bearing will therefore be 6305 J40 (C4)

Range of residual clearance after fitting

Probable range of interference on the shaft (difference between extreme values):

Probable range of interference in the housing (difference between extreme values):

Considering the previous effect ratios, the probable ranges on radial clearance are:

D_{pl} = 23 μm

$$\begin{array}{rcl} \mathsf{D}_{pci} = & \mathsf{D}_{pa} \cdot \mathsf{t}_i = & 13 \ \mu m \ x \ 0.8 \\ & = & 10.5 \ \mu m \\ & \text{for the inner ring} \end{array}$$
$$\begin{array}{rcl} \mathsf{D}_{pce} = & \mathsf{D}_{pl} \cdot \mathsf{t}_e = & 23 \ \mu m \ x \ 0.7 \\ & = & 16 \ \mu m \\ & \text{for the outer ring} \end{array}$$

D_{er} = 41-23 = 18 μm

Range of bearing internal clearance:

According to the laws of probabilities, the range of the residual clearance will be:

The 6305 bearing with a category 4 clearance mounted with k5 and N6 fits has an operating clearance of:

 $\Delta_{Jr} = (D_{pci}^{2} + D_{pce}^{2} + D_{er}^{2})^{1/2}$ $= (10.5^{2} + 16^{2} + 18^{2})^{1/2} = 26 \,\mu\text{m}$

$$J_{f} = J_{rm} \pm D_{Jr}/2 = 11 \pm 13 \,\mu m$$



Radial clearance of radial contact bearings (continued)

→ Choice of internal clearance as a function of shaft and housing fits

The example on the previous page shows that interference fits on shaft and housing require a bearing with increased clearance.

The table below defines the limit fits for the shaft and housing.



➔ Calculation of the residual clearance in operation

The residual clearance in operation is a function of the residual clearance after mounting and the relative temperature differential between shaft and housing.

Materials with different coefficients of expansion

Bearing mounted in a light alloy housing. The difference in the bearing and housing diameters resulting from differential expansion is:

$$\Delta D = (C_2 - C_1) D \cdot \Delta t = 8 \cdot 10^{-6} \cdot D \cdot \Delta t$$

where:

- Δt Operating temperature 20°C (68°F)
- D Bearing outside diameter
- C1 Expansion coefficient of steel = 12 x 10⁻⁶ mm/mm/°C
- C2 Expansion coefficient of the light alloy housing = 20 x 10⁻⁶ mm/mm/°C

The different expansion of the materials will increase the clearance of the outer ring in its housing and can allow it to rotate. This differential expansion must be compensated for by having a tighter fit and using a bearing with increased clearance.

Example

Choice of housing fit for a 6305 bearing (D = 62 mm) mounted in light alloy with an operating temperature of $80^{\circ}C$ (176°F).

With a J7 tolerance, the housing diameter is on average 10 μm larger than the bearing diameter. See page 101.

This value is too high to secure a good retention of the bearing in the housing. Therefore, choosing a P7 housing tolerance with a mean interference of 30 μ m will compensate for the effect of differential expansion at 80°C (176°F).

Choosing a P7 tolerance for the outer ring will lead to a reduction in the radial clearance of the bearing equal to:

If the shaft with a k6 tolerance gives a mean interference of 13,5 μ m on the inner ring, the reduction of the radial clearance due to the inner ring fit is:

The total reduction in the bearing clearance due to fitting is:

One therefore chooses a 6305J40/C4 bearing (clearance category 4: mean radial clearance of $32 \mu m$) to avoid cancelling the clearance during operation at $20^{\circ}C$ (68°F) normal temperature.

 $\Delta t = 60^{\circ}C$ $\Delta D = 8 . 10^{-6} . 62 . 60 = 0.030 mm$

At 80° C, it is 10 μ m + Δ D = 40 μ m

t_e . S_e =0,5 . 29.5 = 15 μm

t_i . S_i = 0.8 . 13,5 =11 μm

 $R_{im} = t_e \cdot S_e + t_i \cdot S_i = 15 + 11 = 26 \ \mu m$



Radial clearance of radial contact bearings (continued)

Temperature difference between shaft and housing

Both the shaft and housing are made of steel, but the temperature of the shaft is higher than that of the housing.

The differential expansion between the bearing inner ring and the outer ring will reduce the radial clearance by the value

 $\Delta J = C1 \times (D \cdot \Delta tl - d \cdot \Delta ta)$

where:

C1	Expansion coefficient of the steel
D	Bearing outside diameter
d	Bearing bore
Δta	Difference between the running temperature of the shaft
	and the room temperature (specified at 20°C or 68°F)
∆ tl	Difference between the running temperature of the housing
	and the room temperature (specified at 20°C or 68°F)

Example

Let us assume that a 6305 bearing (25 x 62) has a residual clearance J_{rm} of 10 μ m after fitting at 20°C (68°F).

In operation:

- the temperature of the shaft and the inner ring is 70°C (158°F)
- the temperature of the housing and the outer ring is 50°C (122°F)

The reduction in radial clearance of the bearing is:	Δ J =12 . 10 $^{\rm 6}$. ((62 . 30) - (25 . 50)) = 7 μm		
The operating residual radial clearance is:	Jrf = Jrm - ∆ J = 10 um - 7 um = 3 µm		

In this case it is recommended to use a bearing from Group 3 increased clearance.

Axial clearance of angular contact bearings

Axial preload

A preload is a permanent axial force applied to the bearings when they are fitted. It is obtained by the penetration of the inner ring with respect to the outer ring of each bearing from the reference position.

Axial penetration and preload

Under load, the rolling element / raceway contact points undergo plastic deformation due to the very high Hertz pressures, giving an axial displacement of one ring in respect to the other. A curve gives the value of the relative displacement of the two rings according to the axial load.



In an assembly with two bearings mounted in opposition, the penetration of one bearing increases the clearance of the other.

In assemblies demanding very high guidance precision (machine-tool spindle, bevel gears, oscillating systems, etc.), a preload must be applied to get rid of the clearance and give optimum rigidity.





Axial clearance of angular contact bearings (continued)

Determining the preload

The preload value P is chosen as a function of the mean axial load applied (Am)

```
P = Am / 3
```

The two preloaded bearings are studied using the diagram of associated penetration curves.

Without an external axial load, the meeting point (P) corresponds to the applied preload that creates on each bearing a penetration of (d1) and (d2) respectively, the total closing of the two bearings being p = d1+d2

When an external axial load A is applied to the assembly, each bearing follows its penetration curve. One of the two bearings is subject to an additional penetration (da) which reduces the penetration of the opposite bearing by as much

To find the loads Fa1 and Fa2 applied to each bearing, the axial load A is positioned between the two curves (points MI and M2).

The axial equilibrium of the shaft is: Fa1 - Fa2 = A

If A exceeds the value Fd (unseating axial load), the opposite bearing gets an operating axial clearance.

Remarks:

The diagram of associated penetration curves is modified by any radial loads applied to the bearings.

As any preload influences the resultant loads applied to the bearings, bearing performances must be calculated taking into account the preload value. Consult SNR for these calculations that bring into play the rigidity characteristics. A preloaded assembly has greater friction drag torque than an assembly with clearance. Its lubrication must therefore be studied with the utmost care.



Adjustment

The adjustment enables an assembly to be given the predetermined axial clearance or preload. This is done by sliding one ring (inner or outer) of one of the two bearings of the assembly. This ring must therefore be loose fitted on its seat.

If the assembly is to have an axial clearance j_a, it is checked using a dial comparator.



If the assembly is to have a preload value p, one starts with any axial clearance J_a and then the loose bearing ring is moved by the value $J_a + p$. This operation is usually achieved with the shaft nut or by adapting the thickness of the adjustment spacers in the housing. The allowed tolerance on a preloaded setting is tight (about half the one permitted for the axial clearance).

Influence of the temperature on the axial clearance of bearings

Modification of clearance on assembly

The axial clearance or preload of a shaft mounted on two angular-contact bearings (ball or tapered roller bearings) can be changed by the operating temperatures.

The assembly opposite schematically illustrates:

- a change in the axial clearance of the assembly due to the difference of axial expansion between the housing and the shaft
- a modification in the outer ring / housing interference that results in a variation of the radial clearance and therefore the axial clearance of the assembly

The total change of the axial clearance of the assembly is the algebraic sum of these two variations.



In an O assembly (case shown in the sketch), the two variations are in opposite directions and may cancel each other out. Conversely, in an X assembly the two variations are in the same direction.



Axial clearance of angular contact bearings (continued)

ightarrow Theoretical calculation of the variation in the axial clearance of an assembly

Variation due to shaft and housing different axial expansion

 $\Delta Ja_1 = (I \cdot C_2 \cdot \Delta t) - (I \cdot C_1 \cdot \Delta t) = (C_2 - C_1) \cdot I \cdot \Delta t$

where:

- I Distance between the bearings
- C1 Expansion coefficient of the shaft
- C2 Expansion coefficient of the housing
- ∆t Difference between the operating temperature and the room temperature (specified at 20°C or 68°F)

Variation due to the modification of the outer ring/housing interference

	Bearing 1	Bearing 2
Temperature at which the outer ring/housing interference is cancelled by the expansion of the housing	$\begin{array}{lll} \Delta t 0_1 = S_1 \ / \ ((\ C_2 \ - \ C_1 \) \ . \ D_1) \\ & D_1, D_2 & \text{Outside diameter} \\ & S_1, S_2 & \text{Diametral interf} \end{array}$	$\Delta t0_2 = S_2 \ / \ ((\ C_2 \ - \ C_1 \) \ . \ D_2)$ are of the bearings erence of the bearings
Variations of interference with temperature	$ \begin{array}{l} \text{If } \Delta t \leq \Delta t 0_1 \\ \Delta \ S_1 = (\ C_2 - C_1 \) \ . \ D_1 \ . \ \Delta t \\ \text{If } \Delta t > \Delta t 0_1 \\ \Delta \ S_1 = S_1 \end{array} $	$ \begin{array}{l} \text{If } \Delta t \leq \Delta t 0_2; \\ \Delta \ S_2 = (\ C_2 \ \ - \ C_1 \) \ . \ D_2 \ . \ \Delta t \\ \text{If } \Delta t > \Delta t 0_1; \\ \Delta \ S_2 = S_2 \end{array} $
Variation of axial clearance due to the modification of the outer ring/housing interference	$ \begin{array}{c c} \Delta \mbox{ Ja}_2 = (K_1 \ . \ te_1 \ . \ \Delta \ S_1) + (K_2 \ . \ te_2 \ . \ \Delta \ S_2) \\ te_1, te_2; \ effect ratio of this interference on the radial clearance page 109 \\ K_1, K_2; \ transformation coefficients of radial clearance into axial clearance \\ K_1 = Y_1 \ / \ 0.8 \\ Y_1, Y_2 \ see page 59 \end{array} \qquad \qquad \begin{array}{c} K_2 = Y_2 \ / \ 0.8 \\ K_2 = Y_2 \ / \ 0.8 \end{array} $	

Total variation in the axial clearance of the assembly

Assembly in X arrangement	$\Delta \operatorname{Ja} = \Delta \operatorname{Ja}_2 + \Delta \operatorname{Ja}_1$
Assembly in O arrangement	Δ Ja = Δ Ja ₂ - Δ Ja ₁

These calculations enable the initial clearance to be fixed in order to get the desired clearance values in operation.

Example

Take an assembly of two 32 210 tapered roller bearings mounted in an O arrangement in an aluminium housing (P7 fit); operating temperature 80°C (176°F):

 $\begin{array}{ll} & = 240 \text{ mm} \\ D_1 = D_2 & = 90 \text{ mm} \\ C_2 - C_1 & = 8 \times 10\text{-}6 \text{ mm/mm/°C} \\ Y_1 = Y_2 & = 1.43 \\ S_1 = S_2 & = 0.0335 \text{ mean value} \\ \Delta t & = 60^\circ \text{C} (140^\circ \text{F}) \\ te_1 = te_2 = 0.5 \text{ see page } 109 \end{array}$

Variation in axial clearance due to axial expansion Δ Ja₁ Δ Ja₁ = 8 . 10⁻⁶ . 240 . 60 = 0.114 mm

Variation due to the modification in the outer ring/housing interference

	Bearing 1	Bearing 2	
Temperature at which the outer ring/housing interference is cancelled by the expansion of the housing	$\Delta t0_1 = \Delta t0_2 = 0.0335 / (8.10-6.90) = 47^{\circ}C$		
Variations of interference with temperature	$\begin{array}{l} \Delta t > \Delta t0_1 \text{ and } \Delta t0_2 \\ \Delta S_1 = \Delta S_2 = 0.0335 \end{array}$		
Variation of axial clearance due to the modification in outer ring/housing interference	$\Delta \operatorname{Ja}_2 = ((1.43 / 0.8) \cdot 0.5 \cdot 0.0335) + (1.78 \cdot 0.5 \cdot 0.0335) = 0.060$		

Total variation in the axial clearance of the assembly

 Δ Ja = + 0.060 -0.114 = -0.054

The following graphs illustrate the variation in axial clearance of the assembly according to the operating temperature in the X and O assembly arrangements.

Assembly in O arrangement



Assembly in X arrangement



